

PARTS LIST FOR WP-4000-4MHB/RB

ENGINE OIL GRADE:

HONDA/ SUBARU: SAE10W-30

ENGINE OIL CAPACITY: 20 oz.

PUMP OIL GRADE: Mi-T-M Pump Oil AW-4085-0016

PUMP OIL CAPACITY: 16 oz. NOZZLE SIZE: 3.0

This Parts Listing has been compiled for your benefit. You can be assured your Mi-T-M Cold Water Pressure Washer was constructed and designed with quality and performance in mind using over 25 years experience in the pressure washer business. Each component has been rigorously tested to insure the highest level of acceptance.

The contents of this Parts Listing are based on the latest product information available at the time of publication. Mi-T-M reserves the right to make changes in price, color, materials, equipment, specifications or models at any time without notice.

WARNING

THIS IS A HIGH PRESSURE, COLD WATER PRESSURE WASHER. CAUTION SHOULD BE OBSERVED WHEN USING OR REPAIRING THIS UNIT! READ AND FOLLOW THE SAFETY WARNINGS LISTED BELOW BEFORE ATTEMPTING ANY REPAIRS ON THIS PRESSURE WASHER!

SAFETY WARNINGS

- 1. NEVER alter or modify the equipment. Be sure any accessory items and system components being used will withstand the pressure developed. Use only genuine Mi-T-M parts for repair of your pressure washer. Failure to do so can cause hazardous operating conditions and will VOID warranty.
- 2. NEVER make adjustments on machinery while the unit is connected to the engine without first removing the ignition cable from the spark plug.

 Turning over the machinery by hand during adjustment or cleaning might start the engine and machinery with it, causing serious injury to the operator.
- 3. Know how to stop and bleed pressures quickly. Be thoroughly familiar with controls.
- 4. Before servicing the unit, turn unit off, relieve the water pressure and allow the unit to cool down. Do not make repairs while the unit is running. Service in a clean, dry, flat area. Be especially careful to properly dispose of any flammable materials.
- 5. After testing the machine, DO NOT leave the pressurized unit unattended. Shut off the unit and release trapped pressure before leaving.


Table of Contents

SPECIFICATIONS	.3
FRAME ASSEMBLY	.4
PUMP ASSEMBLY 3-0288	6

SPECIFICATIONS

MODEL NUMBER	WP-4000-4MHB	WP-4000-4MRB					
Operating Pressure (PSI/Bar):	4000/276						
High Pressure Nozzle:	3.5						
Water Volume (GPM/lpm):	3.4/12.9						
Engine:	Honda	Subaru					
Horsepower	13.0	13.5					
Engine Type	4 Stroke, Overhead Cam, Single Cylinder	4 Stroke, Overhead Valve, Single Cylinder					
Oil Type	SAE10)W-30					
Oil Capacity (oz./liters)	37.0/1.1	40.5/1.2					
Fuel Type	Unleaded Gasoline 8	36 Octane Minimum					
Low Oil Protection	Oil Alert™	Oil Sensor					
Fuel Capacity (gallon/ liters)	1.7/6.5	1.85/7.0					
Starting	Recoil						
Maximum No Load RPM	3600 (+/- 1	100) RPM					
Pump:	Direct Driven, Oil E	Bath, Triplex Piston					
Oil Type	Mi-T-M Pump Oil AW-4085-0016						
Oil Capacity (oz./liters)	16 oz.						
Plungers	Ceramic Coated						
Manifold	Forged Brass						
Valves	Stainless Steel						
Unloader	Preset						
Heat Dump Valve	Relieves heated water during unloader bypass stage						
Detergent Injector	Low pressure down stream from pump						
Unit Net Weight (lbs/Kg)	142/64.4						
Unit Shipping Weight (lbs/Kg)	192/87.1						
Unit Net Dimension (in/cm)	40Lx22.5Wx24.5H/101.6Lx57.2Wx62.3H						
Unit Shipping Dimension (in/cm)	32.5Lx22.5Wx28.5H/82.6Lx57.2Wx72.4H						

FRAME ASSEMBLY



FRAME ASSEMBLY FOR WP-4000-4MHB_RB										
REF.#	DESCRIPTION	PART #	QTY.		REF. # DESCRIPTION		PART #	QTY.		
1	Decal- Die Cut 4000	34-1400	1		20	Bolt	27-0121	4		
2	Decal- Work Pro Placard	34-0737	1		21	Flatwasher	28-0023	8		
3	Decal- Warning/Caution/Operation (See 34-9014)	N/A Sep.	1		22	Locknut	30-0159	4		
4	Front Handle Assy	7-0194A01	1		23	Decal- Caution: Risk of Fire(See 34-9014)	N/A Sep.	1		
5	Large JP Frame	5-0254A53	1		24	Decal- Warning: Muffler Hot (See 34-9014)	N/A Sep.	1		
6	Nozzle- 1503.5	18-0258	1		25	Engine- 13.0 H.P. Honda	1-0086	1		
-	Nozzle- 2503.5	18-0259	1		-	Engine- 13.5 H.P. Subaru	1-0156	1		
-	Nozzle- 6540	18-0148	1		26	Key	43-0078	1		
7	Grommet	33-0001	5		27	27 Pump		1		
8	Locknut	30-0157	10		28 Washer		28-0022	4		
9	Isolator	14-0008	2		29 Lockasher		29-0008	4		
10	Bolt	27-0068	2		30 Bolt		27-0118	4		
11	Bolt	27-0067	4		31 Detergent Hose		19-0233	1		
12	Decal- Data Plate	N/A	1		32 O-ring (Replacement Only)		25-0122	-		
13	Wheel	14-0113	2		33 Decal- Warning: Risk of Injection (See 34-9014)		N/A Sep.	1		
14	Nut	30-0117	2		34	Lance Assembly	16-0366	1		
15	Elbow	24-0105	1		35	Pressure Hose	15-0270	1		
16	Filter	19-0001	1		36	Gun/Wand Assembly	16-0441	1		
17	Garden Hose Swivel	23-0096	1		37	Quick Connect	17-0005	1		
18	O-ring (Replacement Only)	25-0123	2			Safety Decal Kit (Inc. 3, 23-24. 33)	34-9014			
19	Quick Connect	17-0004	1	*Must Order in One Foot Lengths						

6

3-0288-101007-JJT

PUMP ASSEMBLY (3-0288)												
REF.#	DESCRIPTION	PART #	QTY.	REF.#	DESCRIPTION	PART#	QTY.		REF.#	DESCRIPTION	PART #	QTY.
1	Set Screw	27-9596	1	23	O-ring	25-0317	1	Ī	45	Screw	27-9598	8
2	Nut	30-6024	1	24	Connecting Rod	46-1252	3	Ī	46	Orfice	46-1250	1
3	Barrel	8-0551	1	25	Piston	46-1247	3	Ī	47	O-ring	25-0500	1
4	Button- Spring	8-0501	2	26	Screw	27-9597	4		48	O-ring	25-0596	1
5	Unloader Spring	49-0157	1	27	Flange	46-1244	1		49	O-ring	25-0407	2
6	O-ring	25-0526	1	28	Oil Seal	26-0192	1		50	Detergent Injector	46-1251	1
7	Unloader Piston	8-0565	1	29	Retaining Ring	46-0667	1		51	Non Return Valve	46-1249	1
8	O-ring	25-0163	1	30	Bearing	48-0059	1		52	O-ring	25-0406	1
9	Back-up Ring	25-0589	1	31	Screw	27-8886	1		53	Compression	8-0520	1
10	Piston Guide	8-0585	1	32	Crankshaft	46-1253	1		54	Ball	8-0521	1
11	Thermal Relief Valve	22-0408	1	33	Pump Housing	46-1243	1		55	O-ring	25-0371	1
12	Valve Assembly	1	6	34	Oil Seal	26-0193	3		56	Barb Hose	46-0869	1
13	Valve Cap	39-0362	3	35	O-ring	25-0305	3		57	Plug	39-0363	1
14	O-ring	25-0159	4	36	Spacer	46-1248	3		58	Unloader Seat	8-0586	1
15	Bearing cap	46-0725	1	37	Seal	46-0727	3		59	O-ring	25-0255	1
16	Snap ring	46-0676	1	38	O-ring	25-0399	3		60	Unloader- By Pass Jet	8-0528	1
17	Snap ring	46-0732	1	39	Packing Retainer	46-1108	3			Injector Repair (Inc. 1 each 53-55)	70-0293	
18	Ball Bearing	48-0063	1	40	Ring	-	3			Valves (Inc. 6 each 12)	70-0456	
19	Oil Dipstick	39-0090	1	41	Packing	-	3	Ī		Pistons (Inc. 3 each 25)	70-0457	
20	Piston Pin	46-0721	3	42	Support Ring	-	3	Ţ		Water Seals (Inc. 3 each 35, 37, 38, 40, 41)	70-0458	
21	Screw	27-8874	4	43	Pump Head	46-1246	1	Ī		Oil Seals (Inc. 1, 1, 1, 3 each 15, 23, 28, 34)	70-0459	
22	Pump Rear Cover	46-1245	1	44	Lockwasher	29-0153	8	Ī		Support Ring (Inc. 3 each 42)	70-0460	
_									•	Unloader (Inc. 1, 2, 1, 1, 1, 1 each 1-3, 4, 5-40, 14, 49, 57-59)	70-0461	

Manufactured by Mi-T-M 8650 Enterprise Drive, Peosta IA 52068 563-556-7484/ Fax 563-556-1235